


PIROUETTE INSTALLATION



Near the house electric wire drill a hole in the ceiling for a suspension hook (provided by client). Use a dowel to secure the hook in the ceiling.

CAUTION! take into consideration each lamps weight to create a safe hanging system.

Attach the suspension cable to the hook and adjust desired height.

Adjust the length of the lamps electric wire and connect it to the house wire.

Bulb: E27/E26 fitting max 100W

IMPORTANT

The assembly should be carried out by a qualified person, due to the fact that wrong assembly can lead to that the lighting fixture topples or falls resulting in personal injury or damage.

NOTE screws, fittings and suspension cable to fix the light fixture to the ceiling are not included. Choose screws and fittings that are specially suited to the material in your ceiling and have sufficient holding power. If you are uncertain, contact your local specialised dealer.

Feel free to contact us for advice for your situation.

CONTACT

JSPR

T +31 (0) 402692111 INFO@JSPR.EU WWW.JSPR.EU